

For CS1W-NC113

GPN-CS77Y/GPN-CS77T

(Custom No.) X-PLC0179

Input / Output Connector

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20
A21	21	21	B21
A22	22	22	B22
A23	23	23	B23
A24	24	24	B24

*Since the signal name of this item is complex, the mark tube is printed with connector pin numbers.

FCN Male 48-Core

[Product Page](#) **570, 572**

For CS1W-NC133

GPN-CS78Y/GPN-CS78T

(Custom No.) X-PLC0180

Input / Output Connector

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20
A21	21	21	B21
A22	22	22	B22
A23	23	23	B23
A24	24	24	B24

*Since the signal name of this item is complex, the mark tube is printed with connector pin numbers.

FCN Male 48-Core

[Product Page](#) **570, 572**

For CS1W-NC213

GPN-CS79Y/GPN-CS79T

(Custom No.) X-PLC0181

Input / Output Connector

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20
A21	21	21	B21
A22	22	22	B22
A23	23	23	B23
A24	24	24	B24

*Since the signal name of this item is complex, the mark tube is printed with connector pin numbers.

FCN Male 48-Core

[Product Page](#) **570, 572**

For CS1W-NC233

GPN-CS82Y/GPN-CS82T

(Custom No.) X-PLC0182

Input / Output Connector

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20
A21	21	21	B21
A22	22	22	B22
A23	23	23	B23
A24	24	24	B24

*Since the signal name of this item is complex, the mark tube is printed with connector pin numbers.

FCN Male 48-Core

[Product Page](#) **570, 572**

For CS1W-NC413

GPN-CS83Y/GPN-CS83T

(Custom No.) X-PLC0183

Input / Output Connector 1

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20
A21	21	21	B21
A22	22	22	B22
A23	23	23	B23
A24	24	24	B24

FCN Male 48-Core

[Product Page](#) **570, 572**

For CS1W-NC413

GPN-CS84Y/GPN-CS84T

(Custom No.) X-PLC0184

Input / Output Connector 2

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20
A21	21	21	B21
A22	22	22	B22
A23	23	23	B23
A24	24	24	B24

*Since the signal name of this item is complex, the mark tube is printed with connector pin numbers.

FCN Male 48-Core

[Product Page](#) **570, 572**

For CS1W-NC433

GPN-CS85Y/GPN-CS85T

(Custom No.) X-PLC0185

Input / Output Connector 1

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20
A21	21	21	B21
A22	22	22	B22
A23	23	23	B23
A24	24	24	B24

FCN Male 48-Core

[Product Page](#) **570, 572**

For CS1W-NC433

GPN-CS86Y/GPN-CS86T

(Custom No.) X-PLC0186

Input / Output Connector

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20
A21	21	21	B21
A22	22	22	B22
A23	23	23	B23
A24	24	24	B24

*Since the signal name of this item is complex, the mark tube is printed with connector pin numbers.

FCN Male 48-Core

[Product Page](#) **570, 572**

For CS1W-CT021

GPN-CS68Y/GPN-CS68T

(Custom No.) X-PLC0193

Input / Output Connector 1

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20

FCN Male 40-Core

[Product Page](#) **570, 572**

For CS1W-CT021

GPN-CS69Y/GPN-CS69T

(Custom No.) X-PLC0194

Input / Output Connector 2

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20

*Since the signal name of this item is complex, the mark tube is printed with connector pin numbers.

FCN Male 40-Core

[Product Page](#) **570, 572**

For CS1W-CT041

GPN-CS72Y/GPN-CS72T

(Custom No.) X-PLC0195

Input / Output Connector 1

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20

FCN Male 40-Core

[Product Page](#) **570, 572**

For CS1W-CT041

GPN-CS73Y/GPN-CS73T

(Custom No.) X-PLC0196

Input / Output Connector 2

Signal Name	A	B	Signal Name
A1	1	1	B1
A2	2	2	B2
A3	3	3	B3
A4	4	4	B4
A5	5	5	B5
A6	6	6	B6
A7	7	7	B7
A8	8	8	B8
A9	9	9	B9
A10	10	10	B10
A11	11	11	B11
A12	12	12	B12
A13	13	13	B13
A14	14	14	B14
A15	15	15	B15
A16	16	16	B16
A17	17	17	B17
A18	18	18	B18
A19	19	19	B19
A20	20	20	B20

*Since the signal name of this item is complex, the mark tube is printed with connector pin numbers.

FCN Male 40-Core

[Product Page](#) **570, 572**

*When ordering, put the custom No. at the end of the model number. (See the product page for the model number)

*Be sure to confirm the signal name upon placing an order as it may slightly differ from the PLC manufacturer manual, in order to distinguish identical signal names.

Pins with no signal name are not connected. Cables are selected according to the number of required pins.