















## Keyence KV / KZ Series Supported Cable Pin Assignment Figure

<b>KV-5500 KV-5000</b> <b>KV-3000 KV-1000</b> <b>GP□-K45Y/GP□-K45T</b> (Custom No.) X-PLC0105 Input / Output Connector  <b>MIL Socket Male 40-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KV-700</b> <b>GP□-K22Y/GP□-K22T</b> (Custom No.) X-PLC0106 Input / Output Connector  <b>MIL Socket Male 20-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KZ-350/300</b> <b>GP□-K23Y/GP□-K23T</b> (Custom No.) X-PLC0107 Input / Output Connector  <b>MIL Socket Male 20-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KZ-C16X</b> <b>GP□-K28Y/GP□-K28T</b> (Custom No.) X-PLC0108 Input Connector  <b>MIL Socket Male 34-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KV-C32XA / XC</b> <b>TA/TAP/TC/TCP</b> <b>TD / KV-C16XTD</b> <b>GP□-K32Y/GP□-K32T</b> (Custom No.) X-PLC0110 Input / Output Connector  <b>MIL Socket Male 34-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KZ-C32X</b> <b>GP□-K29Y/GP□-K29T</b> (Custom No.) X-PLC0109 Input Connector  <b>MIL Socket Male 34-Core</b> Product Page <a href="#">▶556, 560, 562</a>
---	--	--	--	---	--

<b>KV-C64XA / XB / XC</b> <b>TA/TAP/TC/TAP</b> <b>TD / KV-C32XTD</b> <b>GP□-K35Y/GP□-K35T</b> (Custom No.) X-PLC0111 (Custom No.) X-PLC0112 L-side Connector      H-side Connector  <b>MIL Socket Male 34-Core</b> <b>MIL Socket Male 34-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KZ-C32T</b> <b>GP□-K43Y/GP□-K43T</b> (Custom No.) X-PLC0113 Output Connector  <b>MIL Socket Male 34-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KV-H20S</b> <b>GP□-K46Y/GP□-K46T</b> (Custom No.) X-PLC0115 Input / Output Connector  <b>MIL Socket Male 40-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KV-H40S</b> <b>GP□-K47Y/GP□-K47T</b> (Custom No.) X-PLC0116 (Custom No.) X-PLC0117 X1 / Y1 Connector      X2 / Y2 Connector  <b>MIL Socket Male 40-Core</b> <b>MIL Socket Male 40-Core</b> Product Page <a href="#">▶556, 560, 562</a>
---	--	--	--

<b>KV-SC20 (V)</b> <b>GP□-K44Y/GP□-K44T</b> (Custom No.) X-PLC0114 Input / Output Connector  <b>MIL Socket Male 34-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KV-H20G</b> <b>GP□-K52Y/GP□-K52T</b> (Custom No.) X-PLC0119 CX / Y1 Connector  <b>MIL Socket Male 40-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KV-H20G</b> <b>GP□-K49Y/GP□-K49T</b> (Custom No.) X-PLC0118 X1 / Y1 Connector  <b>MIL Socket Male 40-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KL-16CX / 16CT</b> <b>GP□-K25Y/GP□-K25T</b> (Custom No.) X-PLC0120 Input / Output Connector  <b>MIL Socket Male 26-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KL-32CX/32CT</b> <b>GP□-K26Y/GP□-K26T</b> (Custom No.) X-PLC0121 CN1 Connector  <b>MIL Socket Male 26-Core</b> Product Page <a href="#">▶556, 560, 562</a>	<b>KL-32CX/32CT</b> <b>GP□-K27Y/GP□-K27T</b> (Custom No.) X-PLC0122 CN2 Connector  <b>MIL Socket Male 26-Core</b> Product Page <a href="#">▶556, 560, 562</a>
---	--	--	--	--	---

\*When ordering, put the custom No. at the end of the model number. (See the product page for the model number)

\*Be sure to confirm the signal name upon placing an order as it may slightly differ from the PLC manufacturer manual, in order to distinguish identical signal names.

Pins with no signal name are not connected. Cables are selected according to the number of required pins.

Connector Included Cable Documents